



# **Revitalising Facial Sauna**



**Instruction Manual** 



#### READ ALL INSTRUCTIONS BEFORE USE. SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE. FOR HOUSEHOLD USE ONLY.

# **IMPORTANT SAFEGUARDS:**

#### WHEN USING ELECTRICAL PRODUCTS, ESPECIALLY WHEN CHILDREN ARE PRESENT, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING THE FOLLOWING:

- This appliance can be used by children aged from 14 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Use this appliance for the intended use as described in this booklet. DO NOT use attachments not recommended by HoMedics.
- NEVER operate the appliance if it has been damaged. Return it to the HoMedics Service Centre for examination and repair.
- Keep away from heated surfaces.
- NEVER drop or insert any object into any opening.
- D0 NOT attempt to repair the appliance. There are no user serviceable parts.
   For service, send to a HoMedics Service Centre. All servicing of this appliance must be performed by authorised HoMedics service personnel only.
- This product requires a 220-240 V AC power.
- Do not use while bathing.
- NEVER operate the appliance with wet hands.
- Do not place or store appliance where it can fall or be pulled into the bath or sink.
- · Do not place or drop into water or other liquid.
- Do not reach for an appliance that has fallen into water. Unplug immediately.

This appliance MUST NOT be intended for use in the bathroom.
 IMPORTANT: Always switch off and unplug this appliance immediately after

#### using. SAFETY CAUTIONS:

# PLEASE READ THIS SECTION CAREFULLY BEFORE USING THE APPLIANCE.

- If you have any concerns regarding your health, consult a doctor before using this appliance.
- Individuals with pacemakers and pregnant women should consult a doctor before using this appliance.
- DO NOT use on an infant, invalid or on a sleeping or unconscious person. DO
  NOT use on sensitive skin or on a person with poor blood circulation.
- This appliance should NEVER be used by any individual suffering from any
  physical ailment that would limit the user's capacity to operate the controls.
- NEVER use directly on swollen or inflamed areas or skin eruptions.
- An appliance should not be left unattended when plugged in.
- Use this appliance only for its intended use as described in this manual.
- Do not use any attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug. See Warranty
  instructions at the back of this booklet if this product is not working properly,
  or it has been dropped, damaged, or dropped into water.
- If the power cord on the appliance is damaged, or otherwise does not function, do not use the product. Return to authorised service station for replacement of power cord or repair, to avoid hazard.
- Keep the cord away from heated surfaces.
- Never place the appliance on a soft surface such as a bed, or a couch. Always place on a level surface.
- · Never use while sleepy or drowsy.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- · Unplug cord before filling. Fill pan with water only. Do not overfill.
- Do not use if there are open wounds or a rash on the face.
- · Consult a doctor before using this appliance in the following cases: fever,

inflammation, pain, if you are currently under a doctor's care, or are taking medicine.

- Do not use after oral or facial surgery of any kind, including dental cleaning with the use of local anaesthetics.
- · Do not use on sensitive skin on the face.
- Do not wrap the cable around the body of the appliance.
- · Always unplug the appliance from the mains when not in use.
- If the mains cord (or swivel connector becomes damaged), stop using the appliance immediately. As it is not repairable, the item must be discarded.

This product contains small parts that may present a choking hazard for young children.

### MAINTENANCE:

- · Disconnect wall plug before emptying water from unit.
- · Allow appliance to cool before removing facial mask from base.
- · Pour out excess water from evaporation bowl.
- Wipe facial mask and evaporation bowl after use.

#### Cleaning

- Always unplug the appliance from the electrical outlet and let cool before cleaning.
- Empty excess water and wipe dry the interior of the facial mask and rim.
- Remove grate from base by gently prying it out with a screwdriver or dull butter knife. Clean internal cavity with damp cloth. Snap back into place making sure that the notch of the grate clips on to the adjustable steam sliding button.
- Wipe the base with a clean, damp cloth, then polish it lightly with a dry one.
   Never immerse the unit.
- Do not immerse the base in any liquid to clean.
- Never use abrasive cleaners, brushes, gasoline, kerosene, glass/furniture polish or paint thinner to clean.
- Do not attempt to repair the unit. There are no user serviceable parts. For service, send the unit to the HoMedics address listed in the warranty section.
   WARNING! All mineral residue must be removed completely after each use. Use of the facial sauna without proper cleaning could result in uncontrollable steam production. Lime residues must be removed by commercial descaling agents, suitable for stainless steel, according to the manufacturer's instructions.
   DO NOT clean facial mask in dishwasher. It is not dishwasher proof. Hand wash only with a mild detergent.

#### Storage

Place Revitalising Facial Sauna in a clean, dry location, out of the reach of children. Do not wrap the power cord around the unit as this may cause damage. Do not hang the unit by its power cord. Loosely coil the cord and secure with a twist tie.

#### Plug (FAC-2B-GB)

If the plug on this appliance is damaged, it can be replaced with a BS 1363 plug, fitted with a 3A BS 1362 fuse. Only use a 3 amp fuse with this appliance. Care must be taken when changing the plug. If in doubt, contact a qualified electrician.



#### WEEE explanation

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

# **PRODUCT FEATURES:**

The Revitalising Facial Sauna provides a deep cleansing facial steam bath that opens up the pores of the skin to help cleanse impurities and aid make-up removal.



# **OPERATING INSTRUCTIONS:**



- indicator. DO NOT fill cup over the highest level fill line. 3. Place attachment on the steam chamber as shown, (Figure 2). Line up Note: Ensure that the electrical cord loops below the electrical outlet to form
- notches and turn counterclockwise to lock. 4. Plug into a standard 220-240 V AC plug socket.
- 5. Press 'On' button red LED will illuminate.
- 6. Slide steam adjuster to the right to release more steam, or to the left to reduce steam output.
- 7. After approximately 15 minutes steam will begin to rise. Slowly and gently place face on rim of the mask. (Figure 3) CAUTION: Steam will be hot! If you feel discomfort, move your face
- away from the facial mask to a comfortable distance. 8. Every few minutes slightly vary the position of your face to provide a more even sauna, remaining in a static position near the steamer for too long can cause some discomfort and potential scalding.
- 9. After use, unplug the unit and drain away any excess water. After unit has cooled down, clean with a damp cloth.

CAUTION: Unplug the unit after use.

electrical outlet.

a 'Drip loop'. This will prevent water from running down the cord into the

# HOMEDICS®

# TWO YEAR GUARANTEE

HoMedics LLC. guarantees this product from defect in material and workmanship for a period of 2 years from the date of purchase, except as noted below. This HoMedics product guarantee does not cover damage caused by misuse or abuse; accident; the attachment of any unauthorised accessory; alteration to the product; or any other conditions whatsoever that are beyond the control of HoMedics. This guarantee is effective only if the product is purchased and operated in the UK / EU. A product that requires modification or adaptation to enable it to operate in any country other than the country for which it was designed, manufactured, approved and / or authorised, or repair of products damaged by these modifications is not covered under this guarantee. HoMedics shall not be responsible for any type of incidental, consequential or special damages.

To obtain guarantee service on your product, return the product post-paid to your local service centre along with your dated sales receipt (as proof of purchase). Please refer to 'HoMedics Service Centre' information leaflet for details of your local service centre. Upon receipt, HoMedics will repair or replace, as appropriate, your product and return it to you, post-paid. Guarantee is solely through HoMedics Service Centre. Service of this product by anyone other than the HoMedics Service Centre voids the guarantee.

This guarantee does not affect your statutory rights.

#### **HoMedics Service Centre**

HoMedics Group Ltd, HoMedics House, Somerhill Business Park, Five Oak Green Road, Tonbridge, Kent TN11 0GP, UK.

T +44 (0) 1732 360783 e support@homedics.co.uk www.homedics.co.uk