

mySpa[™]
by
HOMEDICS[®]



Register your product today at
www.homedicsgroup.com/register

Facial Cleansing Brush



Instruction Manual

FAC-500A-MYA-GB

2 year
guarantee

READ ALL INSTRUCTIONS BEFORE USE.
SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.
FOR HOUSEHOLD USE ONLY.

IMPORTANT SAFEGUARDS:

WHEN USING ELECTRICAL PRODUCTS, ESPECIALLY WHEN CHILDREN ARE PRESENT, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING THE FOLLOWING:

- If you have any concerns regarding your health, consult a doctor before using this appliance.
- Only use this appliance for the intended use as described in this booklet.
- This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance.
- This appliance should NEVER be used by any individual suffering from any physical ailment that would limit the user's capacity to operate the controls.
- DO NOT use attachments not recommended by HoMedics.
- Keep away from heated surfaces.
- Individuals with pacemakers and pregnant women should consult a doctor before using this appliance.
- DO NOT use on an infant, invalid or on a sleeping or unconscious person.
- DO NOT use on sensitive, very dry or damaged skin or directly on swollen or inflamed areas or skin eruptions. If you have circulatory or skin problems consult your doctor before using.
- Do not use on irritated, sunburned or chapped skin, or on any area with dermatological problems.
- Use should be easy and painless. If you experience nail or skin irritation, or hand discomfort when using this product, discontinue use. If a more extreme reaction occurs, consult your doctor.
- If you feel any discomfort whilst using this appliance, discontinue use and consult your doctor.
- For external use only.
- This is a non-professional appliance, designed for personal use.
- Do not use for longer than the recommended time of 5 minutes.

BATTERY CAUTIONS:

- Follow equipment instructions carefully and always use the recommended type of battery.
- For best results use AA size LR6 Alkaline batteries.
- Replace all batteries at the same time. Do not mix old and new batteries or batteries of different types or brands.
- We do not recommend the use of rechargeable batteries.
- DO NOT put batteries in fire.
- DO NOT puncture, crush, dent or dismantle batteries.
- DO NOT attempt to revive primary batteries by heating, charging or other means.
- DO NOT allow children to fit batteries without adult supervision.
- DO NOT short circuit batteries by connecting the + and – terminals together.
- Keep batteries out of the reach of young children.
- Seek medical advice if you believe a battery has been swallowed.

FITTING THE BATTERIES

- The Facial Cleansing Brush uses two AA size LR6 Alkaline batteries.
- To fit the batteries, remove the battery cover by pulling the battery cover away from the device until the two parts come apart.
- Insert the batteries taking care to observe the correct polarity +ve to +ve and –ve to –ve (Fig 1)
- Replace the battery cover by firmly pushing it into position.




Fig 1

MAINTENANCE

Regular care and cleaning is essential to maintain your Facial Cleansing Brush in peak working condition. Cleaning and user maintenance shall not be made by children without supervision. Regularly check the device for signs of damage.

To Store

Store attachment and unit in a safe, dry place, out of children's reach.


To Clean

Clean the unit and brush head after each use. Clean the outside of the product using a damp cloth and dry thoroughly before using. To clean the brush head, remove from the unit and wash in warm soapy water.


DO NOT use abrasive cleaners.

DO NOT use petroleum based or flammable cleaning agents because of fire risk. Dependent on use we recommend that you replace your brush head every 3-4 months to ensure the brushes performance is maintained. For replacement parts contact your local Homedics Service Centre.

Battery directive

 This symbol indicates that batteries must not be disposed of in the domestic waste as they contain substances which can be damaging to the environment and health. Please dispose of batteries in designated collection points.

WEEE explanation

 This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

PRODUCT FEATURES:



(Colours may vary)



Exfoliation/Cleansing
Brush Head for
body and face

Normal Brush
Head for facial
cleansing
(Select models only)

Sensitive Brush
Head for facial cleansing
of sensitive skin
(Select models only)

Sponge for
hydration
(Select models
only)

Wrinkle reducer to
help skin elasticity
(Select models only)

- Water resistant unit for use in shower or bath, for convenient facial cleansing and exfoliation.
- Comfort grip for ease of use and total control.
- Storage stand for easy storage.

INSTRUCTIONS FOR USE

Applying attachment

1. Switch the Facial Cleansing Brush to the off position (OFF).
2. Push the brush head attachment onto the head of the hand unit until it locks into position with a click (Fig 2).
3. Switch the unit on (ON).




Fig 2

Removing the brush attachment

1. Switch the Facial Cleansing Brush to the off position (OFF)
2. Pull the attachment away from the device with one hand whilst holding the device with the other hand.
3. See Maintenance section for instructions on how to clean and care for the brush attachments.

To cleanse the face (Normal Brush, Sensitive Brush & Exfoliating Brush)

1. Remove any eye make-up by hand before using this device. It is not designed to remove eye make-up.
2. Wet your skin with warm water.
3. Attach the desired brush head to the device following the instructions above.
4. Wet the brush with warm water and apply a facial cleanser solution of your choice (not included) to the brush head.
5. Turn the device on and gently apply the brush to your skin working in circular motions on your face to deeply cleanse the skin. Keep the brush head square to your skin this will avoid any excess spray from the device.
Please note: ensure the skin is kept damp with product / water and the unit is constantly moving in circular movements to avoid dragging the skin
6. Concentrate for approximately 10 seconds per cheek, 20 seconds on the forehead and 20 seconds on the nose and chin area.
Please note: keep away from the delicate eye area.
7. Rinse your face with warm water and gently pat dry with a towel.
Recommendation: it is recommended to cleanse your face with the normal or sensitive brush before using the exfoliating brush.

Using the facial sponge:

1. Follow instructions above on cleansing face
2. Attach the facial sponge following the above instructions
3. Apply facial cream directly to the facial sponge
4. In a circular motion, massage the face cream to your facial area, reapplying additional face cream when needed.

Using the wrinkle reducer:

1. Attached the wrinkle reducer attachment following the instructions above
2. Turn the device on and gently apply the device to your skin working in circular motions. Use the wrinkle reducer on cheeks, around the lip area and on the neck area.
Please note: Keep away from delicate eye area.

The logo for mySpa by HoMedics. The word "mySpa" is in a large, lowercase, sans-serif font with a trademark symbol. Below it, "by" is in a smaller font, and "HoMEDICS" is in a bold, uppercase, sans-serif font with a registered trademark symbol.

TWO YEAR GUARANTEE

HoMedics LLC. guarantees this product from defect in material and workmanship for a period of 2 years from the date of purchase, except as noted below. This HoMedics product guarantee does not cover damage caused by misuse or abuse; accident; the attachment of any unauthorised accessory; alteration to the product; or any other conditions whatsoever that are beyond the control of HoMedics. This guarantee is effective only if the product is purchased and operated in the UK / EU. A product that requires modification or adaptation to enable it to operate in any country other than the country for which it was designed, manufactured, approved and / or authorised, or repair of products damaged by these modifications is not covered under this guarantee. HoMedics shall not be responsible for any type of incidental, consequential or special damages.

To obtain guarantee service on your product, return the product post-paid to your local service centre along with your dated sales receipt (as proof of purchase). Please refer to 'HoMedics Service Centre' information leaflet for details of your local service centre. Upon receipt, HoMedics will repair or replace, as appropriate, your product and return it to you, post-paid. Guarantee is solely through HoMedics Service Centre. Service of this product by anyone other than the HoMedics Service Centre voids the guarantee.

This guarantee does not affect your statutory rights.

HoMedics Service Centre

HoMedics Group Ltd,
HoMedics House,
Somershill Business Park,
Five Oak Green Road,
Tonbridge,
Kent TN11 0GP, UK.

T +44 (0) 1732 360783
e support@homedics.co.uk
www.homedics.co.uk

